
sparco SIZE GUIDE

HELMETS

	XS	S	M	ML	L	XL	XXL
HEAD SIZE (CM)	53-54	55-56	57-58	59	60	61	62
HEAD SIZE (IN)	20.8-21.1	21.5-22	22.4-22.8	23.2	23.5	24	24.5



HELMET SIZING

Carefully measure around your head, above the ears. Take the measurement, in inches or centimetres, referring to the chart for correct, hat/helmet size. Do not guess your size as helmets must fit snugly and securely before engaging in any activity.